




Installation manual



Split system air conditioners



FDXM25F3V1B
FDXM35F3V1B
FDXM50F3V1B
FDXM60F3V1B

FDXM25F3V1B9
FDXM35F3V1B9
FDXM50F3V1B9
FDXM60F3V1B9

Installation manual
Split system air conditioners

English

Table of Contents

Table of Contents

1 About the documentation	2
1.1 About this document.....	2
2 Specific installer safety instructions	2
3 About the box	3
3.1 Indoor unit.....	3
3.1.1 To remove the accessories from the indoor unit.....	4
4 Unit installation	4
4.1 Preparing the installation site	4
4.1.1 Installation site requirements of the indoor unit	4
4.2 Mounting the indoor unit.....	4
4.2.1 Guidelines when installing the indoor unit.....	4
4.2.2 Guidelines when installing the ducting.....	5
4.2.3 Guidelines when installing the drain piping.....	6
5 Piping installation	7
5.1 Preparing refrigerant piping	7
5.1.1 Refrigerant piping requirements.....	7
5.1.2 Refrigerant piping insulation	7
5.2 Connecting the refrigerant piping	7
5.2.1 To connect the refrigerant piping to the indoor unit	7
6 Electrical installation	8
6.1 Specifications of standard wiring components	8
6.2 To connect the electrical wiring to the indoor unit	8
7 Commissioning	9
7.1 Checklist before commissioning.....	9
7.2 To perform a test run	9
8 Configuration	10
8.1 Field setting	10
9 Technical data	11
9.1 Wiring diagram	11
9.1.1 Unified wiring diagram legend.....	11

1 About the documentation

1.1 About this document



WARNING

Make sure installation, servicing, maintenance, repair and applied materials follow the instructions from FläktGroup (including all documents listed in "Documentation set") and, in addition, comply with applicable legislation and are performed by qualified persons only. In Europe and areas where IEC standards apply, EN/IEC 60335-2-40 is the applicable standard.



INFORMATION

Make sure that the user has the printed documentation and ask him/her to keep it for future reference.

Target audience

Authorised installers



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you MUST read before installing
 - Format: Paper (in the box of the indoor unit)
- **Indoor unit installation manual:**
 - Installation instructions
 - Format: Paper (in the box of the indoor unit)
- **Installer reference guide:**
 - Preparation of the installation, good practices, reference data,...
 - Format: Digital files on <https://www.daikin.eu>. Use the search function to find your model.

The latest revision of the supplied documentation is published on the regional FläktGroup website and is available via your dealer.

Scan the QR code below to find the full documentation set and more information about your product on the FläktGroup website.

FDXM-F



FDXM-F9



The original instructions are written in English. All other languages are translations of the original instructions.

Technical engineering data

- A **subset** of the latest technical data is available on the regional FläktGroup website (publicly accessible).
- The **full set** of the latest technical data is available on the Daikin Business Portal (authentication required).

2 Specific installer safety instructions

Always observe the following safety instructions and regulations.

General



WARNING

Make sure installation, servicing, maintenance, repair and applied materials follow the instructions from FläktGroup (including all documents listed in "Documentation set") and, in addition, comply with applicable legislation and are performed by qualified persons only. In Europe and areas where IEC standards apply, EN/IEC 60335-2-40 is the applicable standard.

Unit installation (see "4 Unit installation" ▶ 4)



WARNING

Installation shall be done by an installer, the choice of materials and installation shall comply with the applicable legislation. In Europe, EN378 is the applicable standard.



WARNING

Do NOT install the air conditioner at any place where flammable gas may leak out. If the gas leaks out and stays around the air conditioner, a fire may break out.



CAUTION

Appliance NOT accessible to the general public. Install it in a secured area, protected from easy access.

This unit is suitable for installation in a commercial, light industrial, household and residential environment.

	WARNING
	For units using the R32 refrigerant it is necessary to keep any required ventilation openings clear of obstructions.

	WARNING
	If one or more rooms are connected to the unit using a duct system, make sure:

- there are no operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in case the floor area is less than the minimum floor area A (m²).
- no auxiliary devices, which may be a potential ignition source, are installed in the duct work (example: hot surfaces with a temperature exceeding 700°C and electric switching device);
- only auxiliary devices approved by the manufacturer are used in the duct work;
- air inlet AND outlet are connected directly to the same room by ducting. Do NOT use spaces such as a false ceiling as a duct for the air inlet or outlet.

	WARNING
	Do NOT install operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in the ductwork.

	CAUTION
	<ul style="list-style-type: none"> ▪ Make sure the installation of the duct does NOT exceed the setting range of the external static pressure for the unit. Refer to the technical datasheet of your model for the setting range. ▪ Make sure to install the canvas duct so vibrations are NOT transmitted to the duct or ceiling. Use a sound-absorbing material (insulation material) for the lining of the duct and apply vibration insulation rubber to the hanging bolts. ▪ When welding, make sure NOT to spatter onto the drain pan or the air filter. ▪ If the metal duct passes through a metal lath, wire lath or metal plate of the wooden structure, separate the duct and wall electrically. ▪ Install the outlet grille in a position where the airflow will not come into direct contact with people. ▪ Do NOT use booster fans in the duct. Use the function to adjust the fan rate setting automatically (see "8 Configuration" [▶ 10]).

Refrigerant piping installation (see "5 Piping installation" [▶ 7])

	CAUTION
	<ul style="list-style-type: none"> ▪ Incomplete flaring may cause refrigerant gas leakage. ▪ Do NOT re-use flares. Use new flares to prevent refrigerant gas leakage. ▪ Use flare nuts that are included with the unit. Using different flare nuts may cause refrigerant gas leakage.

	CAUTION
	Install the refrigerant piping or components in a position where they are unlikely to be exposed to any substance which may corrode components containing refrigerant, unless the components are constructed of materials that are inherently resistant to corrosion or are suitably protected against corrosion.

	WARNING: FLAMMABLE MATERIAL
	The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.

Electrical installation (see "6 Electrical installation" [▶ 8])

	WARNING
	ALWAYS use multicore cable for power supply cables.

	WARNING
	<ul style="list-style-type: none"> ▪ All wiring MUST be performed by an authorised electrician and MUST comply with the national wiring regulation. ▪ Make electrical connections to the fixed wiring. ▪ All components procured on-site and all electrical construction MUST comply with the applicable legislation.

	WARNING
	<ul style="list-style-type: none"> ▪ If the power supply has a missing or wrong N-phase, equipment might break down. ▪ Establish proper earthing. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earthing may cause electrical shocks. ▪ Install the required fuses or circuit breakers. ▪ Secure the electrical wiring with cable ties so that the cables do NOT come in contact with sharp edges or piping, particularly on the high-pressure side. ▪ Do NOT install a phase advancing capacitor, because this unit is equipped with an inverter. A phase advancing capacitor will reduce performance and may cause accidents.

	WARNING
	Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provides full disconnection under overvoltage category III.

	WARNING
	If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

	WARNING
	<p>Do NOT extend the power supply or the interconnection cable by using wire connectors, wire connection clamps, taped wires, extension cords.</p> <p>These can cause overheating, electric shock or fire.</p>


3 About the box

3.1 Indoor unit

	WARNING: FLAMMABLE MATERIAL
	The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.


4 Unit installation

3.1.1 To remove the accessories from the indoor unit



- a Installation manual
- b Operation manual
- c General safety precautions
- d Washers for hanger bracket
- e Screws for duct flanges
- f Metal clamp
- g Sealing pads: small and large
- h Drain hose
- i Sealing material
- j Insulation piece: Small (liquid pipe)
- k Insulation piece: Large (gas pipe)
- l Tie wraps
- m Washer fixing plate
- n Air filter

- **Spacing.** Mind the following requirements:



- A Minimum distance to the floor: **2.5 m** to avoid accidental touching.
- a Control box
- b Maintenance space
- c Ceiling
- d Floor surface
- e Select the dimension to ensure downward slope of at least 1/100

4.2 Mounting the indoor unit


4.2.1 Guidelines when installing the indoor unit



INFORMATION

Optional equipment. When installing optional equipment, also read the installation manual of the optional equipment. Depending on the field conditions, it might be easier to install the optional equipment first.

- **Ceiling strength.** Check whether the ceiling is strong enough to support the weight of the unit. If there is a risk, reinforce the ceiling before installing the unit.
 - For existing ceilings, use anchors.
 - For new ceilings, use sunken inserts, sunken anchors or other field supplied parts.



- a Anchor
- b Ceiling slab
- c Long nut or turn-buckle
- d Suspension bolt
- e Indoor unit

- **Suspension bolts.** Use W3/8 M10 suspension bolts for installation. Attach the hanger bracket to the suspension bolt. Fix it securely using a nut and washer from the upper and lower sides of the hanger bracket.



- **Ceiling opening size.** Make sure the ceiling opening is within the following limits:

4 Unit installation



WARNING

Installation shall be done by an installer, the choice of materials and installation shall comply with the applicable legislation. In Europe, EN378 is the applicable standard.

4.1 Preparing the installation site

- Provide sufficient space around the unit for servicing and air circulation.



WARNING

Do NOT install the air conditioner at any place where flammable gas may leak out. If the gas leaks out and stays around the air conditioner, a fire may break out.

4.1.1 Installation site requirements of the indoor unit



INFORMATION

The sound pressure level is less than 70 dBA.



CAUTION

Appliance NOT accessible to the general public. Install it in a secured area, protected from easy access.


This unit is suitable for installation in a commercial, light industrial, household and residential environment.



WARNING

For units using the R32 refrigerant it is necessary to keep any required ventilation openings clear of obstructions.

- Use **suspension bolts** for installation.



Class	A (mm)	B (mm)
25~35	740	790
50~60	1140	1190

- a Nut (field supply)
- b Washer (accessories)
- c Hanger bracket
- d Double nut (field supply)
- e Suspension bolt pitch
- f Overall dimension
- g Control box

Installation options




INFORMATION


The unit can be used with bottom suction by replacing the interchangeable plate by the air filter holding plate.

- For bottom suction replace the interchangeable plate and install the air filter (accessory).

1 Remove the interchangeable plate.



2 Reattach the removed interchangeable plate.




- a Air inlet
- b Air outlet
- c Interchangeable plate

3 Attach the air filter (accessory) by pushing down the hooks (2 hooks for 25+35 type, 3 hooks for 50+60 type).

rear suction

bottom suction



- **External static pressure.** Refer to technical documentation to ensure that the unit's external static pressure is not exceeded.

- **Ceiling opening.** (Ceiling with opening for installation)

4 Pass all pipes and wiring through the unit's piping and wiring holes.


5 Make sure that the ceiling is level.

- **Install the unit temporarily.**

6 Attach the hanger bracket to the suspension bolt.

7 Fix the unit securely.

- **Level.** Make sure the unit is level at all four corners using a level or a water-filled vinyl tube.



8 Tighten the upper nut.



NOTICE

Do NOT install the unit tilted. **Possible consequence:** If the unit is tilted against the direction of the condensate flow (the drain piping side is raised), the float switch might malfunction and cause water to drip.

4.2.2 Guidelines when installing the ducting



WARNING

If one or more rooms are connected to the unit using a duct system, make sure:

- there are no operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in case the floor area is less than the minimum floor area A (m^2).
- no auxiliary devices, which may be a potential ignition source, are installed in the duct work (example: hot surfaces with a temperature exceeding $700^{\circ}C$ and electric switching device);
- only auxiliary devices approved by the manufacturer are used in the duct work;
- air inlet AND outlet are connected directly to the same room by ducting. Do NOT use spaces such as a false ceiling as a duct for the air inlet or outlet.



WARNING


Do NOT install operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in the ductwork.

4 Unit installation




CAUTION

- Make sure the installation of the duct does NOT exceed the setting range of the external static pressure for the unit. Refer to the technical datasheet of your model for the setting range.
- Make sure to install the canvas duct so vibrations are NOT transmitted to the duct or ceiling. Use a sound-absorbing material (insulation material) for the lining of the duct and apply vibration insulation rubber to the hanging bolts.
- When welding, make sure NOT to spatter onto the drain pan or the air filter.
- If the metal duct passes through a metal lath, wire lath or metal plate of the wooden structure, separate the duct and wall electrically.
- Install the outlet grille in a position where the airflow will not come into direct contact with people.
- Do NOT use booster fans in the duct. Use the function to adjust the fan rate setting automatically (see "8 Configuration" [▶ 10]).



a Hanging bar
Allowed
Not allowed




- Condensation.** Take measures against condensation. Insulate the complete drain piping in the building.

- Rising piping.** If necessary to make the slope possible, you can install rising piping.


- Drain hose inclination: 0~75 mm to avoid stress on the piping and to avoid air bubbles.
- Rising piping: ≤ 300 mm from the unit, ≤ 625 mm perpendicular to the unit.

- Combining drain pipes.** You can combine drain pipes. Make sure to use drain pipes and T-joints with the correct gauge for the operating capacity of the units.



The ducting is to be field supplied.

- Air inlet side.** Attach the duct and intake-side flange (field supply). For connecting the flange, use screws (accessory).



a Connection screw (accessory)
b Flange (field supply)
c Main unit
d Insulation (field supply)
e Aluminium tape (field supply)

- Filter.** Be sure to attach an air filter inside the air passage on the intake side. Use an air filter with dust collecting efficiency $\geq 50\%$ (gravimetric method). The included filter is not used when the intake duct is attached.
- Air outlet side.** Connect the duct according to the inside dimension of the outlet-side flange.
- Air leaks.** Wind aluminium tape around the intake side flange and duct connection. Make sure there are no air leaks at any other connection.
- Insulation.** Insulate the duct to prevent condensation from forming. Use glass wool or polyethylene foam 25 mm thick.

4.2.3 Guidelines when installing the drain piping

Make sure condensation water can be evacuated properly. This involves:

- General guidelines
- Connecting the drain piping to the indoor unit
- Checking for water leaks

General guidelines

- Drain pump.** For this "high lift type", the drainage sounds will be reduced when the drain pump is installed in a higher location. Recommended height is 300 mm.
- Pipe length.** Keep drain piping as short as possible.
- Pipe size.** Keep the pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 20 mm nominal diameter and 26 mm outer diameter).
- Slope.** Make sure the drain piping slopes down (at least 1/100) to prevent air from being trapped in the piping. Use hanging bars as shown.


To connect the drain piping to the indoor unit



NOTICE

Incorrect connection of the drain hose might cause leaks, and damage the installation space and surroundings.

- Push the drain hose as far as possible over the drain pipe connection.
- Tighten the metal clamp until the screw head is less than 4 mm from the metal clamp part.
- Check for water leaks (see "To check for water leaks" [▶ 7]).
- Install the insulation piece (drain pipe).
- Wind the large sealing pad (= insulation) around the metal clamp and drain hose, and fix it with cable ties.
- Connect the drain piping to the drain hose.



a Drain pipe connection (attached to the unit)
b Drain hose (accessory)
c Metal clamp (accessory)


- d** Large sealing pad (accessory)
- e** Insulation piece (drain pipe) (accessory)
- f** Drain piping (field supply)

NOTICE

- Do NOT remove the drain pipe plug. Water might leak out.
- Use the drain outlet only to discharge the water if the drain pump is not used or before maintenance.
- Insert and remove the drain plug gently. Excessive force may deform the drain socket of the drain pan.


Pull out the plug.

- Do NOT wiggle the plug up and down.



Push in the plug.


- Set the plug and push it in using a Phillips screwdriver.



a Drain plug
b Phillips screwdriver

To check for water leaks

Gradually pour approximately 1 l of water in the drain pan, and check for water leaks.



a Air outlet
b Portable pump
c Bucket
d Refrigerant pipes
e Drain outlet

5 Piping installation

5.1 Preparing refrigerant piping

5.1.1 Refrigerant piping requirements

NOTICE

The piping and other pressure-containing parts shall be suitable for refrigerant. Use phosphoric acid deoxidised seamless copper for refrigerant piping.

- Foreign materials inside pipes (including oils for fabrication) must be $\leq 30 \text{ mg/10 m}$.

Refrigerant piping diameter

Use the same diameters as the connections on the outdoor units:

	Pipe outer diameter (mm)	
Class	Liquid pipe	Gas pipe
25+35	$\varnothing 6.4$	$\varnothing 9.5$
50+60	$\varnothing 6.4$	$\varnothing 12.7$

Refrigerant piping material

Piping material

Phosphoric acid deoxidised seamless copper

Flare connections

Only use annealed material.

Piping temper grade and thickness

Outer diameter (Ø)	Temper grade	Thickness (t) ^(a)	
6.4 mm (1/4")	Annealed (O)	$\geq 0.8 \text{ mm}$	
9.5 mm (3/8")			
12.7 mm (1/2")			

^(a) Depending on the applicable legislation and the maximum working pressure of the unit (see "PS High" on the unit name plate), larger piping thickness might be required.

5.1.2 Refrigerant piping insulation

- Use polyethylene foam as insulation material:
 - with a heat transfer rate between 0.041 and 0.052 W/mK (0.035 and 0.045 kcal/mh°C)
 - with a heat resistance of at least 120°C
- Insulation thickness:

Pipe outer diameter (\varnothing_p)	Insulation inner diameter (\varnothing_i)	Insulation thickness (t)
6.4 mm (1/4")	8~10 mm	$\geq 10 \text{ mm}$
9.5 mm (3/8")	10~14 mm	$\geq 13 \text{ mm}$
12.7 mm (1/2")	14~16 mm	$\geq 13 \text{ mm}$



If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

5.2 Connecting the refrigerant piping

DANGER: RISK OF BURNING/SCALDING

5.2.1 To connect the refrigerant piping to the indoor unit



CAUTION

Install the refrigerant piping or components in a position where they are unlikely to be exposed to any substance which may corrode components containing refrigerant, unless the components are constructed of materials that are inherently resistant to corrosion or are suitably protected against corrosion.




WARNING: FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.

- **Pipe length.** Keep refrigerant piping as short as possible.

6 Electrical installation

- Flare connections.** Connect refrigerant piping to the unit using flare connections.
- Insulation.** Insulate the refrigerant piping on the indoor unit as follows:



A Liquid piping
B Gas piping

a Insulation material (field supply)
b Tie wrap (field supply)
c Insulation pieces: Large (gas pipe), small (liquid pipe) (accessories)
d Flare nut (attached to the unit)
e Refrigerant pipe connection (attached to the unit)
f Unit
g Sealing pads: Medium 1 (gas pipe), medium 2 (liquid pipe) (accessories)

- 1 Turn up the seams of the insulation pieces.
- 2 Attach to the base of the unit.
- 3 Tighten the tie wrap on the insulation pieces.
- 4 Wrap the sealing pad from the base of the unit to the top of the flare nut.



NOTICE

Make sure to insulate all refrigerant piping. Any exposed piping might cause condensation.

6 Electrical installation

	DANGER: RISK OF ELECTROCUTION
	WARNING ALWAYS use multicore cable for power supply cables.
	WARNING If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

6.1 Specifications of standard wiring components



NOTICE

We recommend using solid wires. If stranded wires are used, slightly twist the strands to consolidate the end of the conductor for either direct use in the terminal clamp or insertion in a round crimp-style terminal. Details are described in "Guidelines when connecting the electrical wiring" in the installer reference guide.

Component	Specification
Interconnection cable (indoor↔outdoor)	Only use harmonized wire providing double insulation and suitable for applicable voltage 4-core cable Minimum size 2.5 mm ²

Component	Specification
User interface cable	Only use harmonized wire providing double insulation and suitable for applicable voltage 2-core cable Minimum size 0.75 mm ² Maximum length 500 m

6.2 To connect the electrical wiring to the indoor unit


	WARNING Do NOT extend the power supply or the interconnection cable by using wire connectors, wire connection clamps, taped wires, extension cords. These can cause overheating, electric shock or fire.
--	---

	NOTICE Follow the wiring diagram (delivered with the unit, located on the switch box cover). Make sure the electrical wiring does NOT obstruct proper reattachment of the service cover.
--	---

It is important to keep the power supply and the interconnection wiring separated from each other. In order to avoid any electrical interference, the distance between both wirings should ALWAYS be at least 50 mm.


	NOTICE Be sure to keep the power line and interconnection line apart from each other. Interconnection wiring and power supply wiring may cross, but may NOT run parallel.
--	---

- 1 Remove the service cover.




A Outside the unit
B Inside the unit
a Control box cover
b Connection of interconnection cable (including earth)
c Wiring diagram
d Connection of user interface wiring
e Sealing material (accessory)
f Opening for cables
g Wire

- 2 **User interface cable:** Route the cable through the frame, connect the cable to the terminal block, and fix the cable with a cable tie.
- 3 **Interconnection cable (indoor↔outdoor):** Route the cable through the frame, connect the cable to the terminal block (make sure the numbers match with the numbers on the outdoor unit, and connect the earth wire), and fix the cable with a cable tie.
- 4 Wrap the cables with the sealing material (accessory) to prevent water from entering the unit. Seal all gaps to prevent small animals from entering the system.



A Indoor PCB (assembly)
a Power supply and earth wiring
b Transmission and user interface wiring
c Clamps
X Not allowed
O Allowed

5 Reattach the service cover.



a Interconnection cable
b Power supply cable
c Earth leakage circuit breaker
d Fuse
e User interface

<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	The insulation resistance of the compressor is OK.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
<input type="checkbox"/>	There are NO refrigerant leaks .
<input type="checkbox"/>	The correct pipe size is installed and the pipes are properly insulated.
<input type="checkbox"/>	The stop valves (gas and liquid) on the outdoor unit are fully open.

7 Commissioning



NOTICE

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If NOT, burning of the compressor might be the result.

7.1 Checklist before commissioning

1 After the installation of the unit, check the items listed below.

2 Close the unit.

3 Power up the unit.

<input type="checkbox"/>	You read the complete installation instructions, as described in the installer reference guide .
<input type="checkbox"/>	The indoor units are properly mounted.
<input type="checkbox"/>	In case a wireless user interface is used: The indoor unit decoration panel with infrared receiver is installed.
<input type="checkbox"/>	The outdoor unit is properly mounted.
<input type="checkbox"/>	There are NO missing phases or reversed phases .
<input type="checkbox"/>	The system is properly earthing and the earth terminals are tightened.
<input type="checkbox"/>	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.

7.2 To perform a test run

This task is only applicable when using the BRC1E52 or BRC1E53 user interface. When using any other user interface, see the installation manual or service manual of the user interface.



NOTICE

Do NOT interrupt the test run.



INFORMATION

Backlight. To perform an ON/OFF action on the user interface, the backlight does not need to be lit. For any other action, it needs to be lit first. The backlight is lit for ± 30 seconds when you press a button.


1 Perform introductory steps.

#	Action
1	Open the liquid stop valve and gas stop valve by removing the cap and turning counterclockwise with a hex wrench until it stops.
2	Close the service cover to prevent electric shocks.
3	Turn ON power for at least 6 hours before starting operation to protect the compressor.
4	On the user interface, set the unit to cooling operation mode.

2 Start the test run





#	Action	Result
1	Go to the home menu.	
2	Press at least 4 seconds.	
3	Select Test Operation.	
4	Press.	

8 Configuration

#	Action	Result
5	Press within 10 seconds. 	Test run starts.

3 Check operation for 3 minutes.

4 Stop the test run.

#	Action	Result
1	Press at least 4 seconds. 	The Service Settings menu is displayed.
2	Select Test Operation. 	
3	Press. 	The unit returns to normal operation, and the home menu is displayed.

8 Configuration

- External static pressure setting. See the technical documentation for the range of the external static pressure setting.

8.1 Field setting

Make the following field settings so that they correspond with the actual installation setup and with the needs of the user:

- Air volume when thermostat control is OFF
- Time to clean air filter
- Simultaneous operation system individual settings
- Computerised control (forced OFF and ON/OFF operation)

Setting: Air volume when thermostat control is OFF

This setting must correspond with the needs of the user. It determines the fan speed of the indoor unit during thermostat OFF condition.

1 If you have set the fan to operate, set the air volume speed:

If you want		Then ⁽¹⁾		
Outdoor unit		M	C1/SW	C2/—
General	2MX/3MX/4MX/5MX			
During cooling operation	LL ⁽²⁾	12 (22)	6	01
	Setup volume ⁽²⁾			02
	OFF			03
	Monitoring 1 ⁽²⁾			04
	Monitoring 2 ⁽²⁾			05

	If you want		Then ⁽²⁾		
	Outdoor unit		M	C1/SW	C2/—
	General	2MX/3MX/4MX/5MX			
During heating operation	LL ⁽²⁾	12 (22)	3	01	
	Setup volume ⁽²⁾		02		
	OFF		03		
	Monitoring 1 ⁽²⁾		04		
	Monitoring 3 ⁽²⁾		05		

Setting: Time to clean air filter

This setting must correspond with the air contamination in the room. It determines the interval at which the **TIME TO CLEAN AIR FILTER** notification is displayed on the user interface. When using a wireless user interface, you must also set the address (see the installation manual of the user interface).

If you want an interval of... (air contamination)	Then ⁽²⁾		
	M	C1/SW	C2/—
±2500 h (light)	10(20)	0	01
±1250 h (heavy)			02
No notification		3	02

- 2 user interfaces:** When using 2 user interfaces, one must be set to "MAIN" and the other to "SUB".

Setting: Individual setting in a simultaneous operation system



INFORMATION

This function is for SkyAir outdoor units (**Example:** RZAG) only.

We recommend using the optional user interface to set the slave unit.

Perform the following steps:

- 1 Change the second code number to 02 to perform individual setting on the slave unit.

If you want to set the slave unit as...	Then ⁽²⁾		
	M	C1/SW	C2/—
Unified setting	21(11)	01	01
Individual setting			02

- 2 Perform field setting for the master unit.
- 3 Turn off the main power supply switch.
- 4 Disconnect the remote controller from the master unit and connect it to the slave unit.
- 5 Change to individual setting.
- 6 Perform field setting for the slave unit.
- 7 Turn off the main power supply or, in case of more slave units, repeat the previous steps for all slave units.
- 8 Disconnect the user interface from the slave unit and reconnect it to the master unit.


⁽¹⁾ Field settings are defined as follows:

- M: Mode number – **First number:** for group of units – **Number between brackets:** for individual unit
- SW: Setting number / C1: First code number
- : Value number / C2: Second code number
- : Default

⁽²⁾ Fan speed:

- LL: Low fan speed (set during thermostat OFF)
- L: Low fan speed (set by the user interface)
- Setup volume: The fan speed corresponds to the speed the user has set using the fan speed button on the user interface.
- Monitoring 1, 2, 3: The fan is OFF, but runs for a short time every 6 minutes to detect the room temperature by LL (Monitoring 1), Setup volume (Monitoring 2) or L (Monitoring 3).

It is not necessary to rewire the remote controller from the master unit if the optional user interface is used. (However, remove the wires attached to the user interface terminal board of the master unit)




A Master unit
B Slave unit
a Interconnection cable
b Power supply cable
c Earth leakage circuit breaker
d Fuse
e1 Main user interface
e2 Optional user interface

Setting: Computerised control (forced OFF and ON/OFF operation)

Wire specifications and how to perform wiring

Connect input from outside to terminals T1 and T2 of the terminal block for user interface (there is no polarity).



Wire specification	
Wire specification	Sheathed vinyl cord or cable (2 wire)
Gauge	0.75~1.25 mm ²
External terminal	Contact that can ensure the minimum applicable load of 15 V DC, 10 mA.

Actuation

Forced OFF	ON/OFF operation	Input from protection device
Input ON stops operation (impossible by user interface)	Input OFF → ON: Turns the unit ON	Input ON enables control by user interface
Input OFF enables control by user interface	Input ON → OFF: Turns the unit OFF	Input OFF stops operation: Triggers A0 error code

How to select FORCED OFF and ON/OFF OPERATION

- 1 Turn on the power and then use the user interface to select operation.
- 2 Change setting:

If you want...	Then ⁽¹⁾		
	M	C1/SW	C2—
Forced OFF	12 (22)	1	01
ON/OFF operation			02
Input from protection device			03

9 Technical data

- A **subset** of the latest technical data is available on the regional FläktGroup website (publicly accessible).
- The **full set** of the latest technical data is available on the Daikin Business Portal (authentication required).

9.1 Wiring diagram

9.1.1 Unified wiring diagram legend

For applied parts and numbering, refer to the wiring diagram on the unit. Part numbering is by Arabic numbers in ascending order for each part and is represented in the overview below by "*" in the part code.

Symbol	Meaning	Symbol	Meaning
—	Circuit breaker	—	Protective earth
—		—	Noiseless earth
—		—	Protective earth (screw)
●—	Connection	Ⓐ, Ⓛ	Rectifier
—	Connector	—	Relay connector
—	Earth	—	Short-circuit connector
—	Field wiring	—	Terminal
—	Fuse	—	Terminal strip
—	Indoor unit	○ ●	Wire clamp
—	Outdoor unit	—	Heater
—	Residual current device		

Symbol	Colour	Symbol	Colour
BLK	Black	ORG	Orange
BLU	Blue	PNK	Pink
BRN	Brown	PRP, PPL	Purple
GRN	Green	RED	Red
GRY	Grey	WHT	White
SKY BLU	Sky blue	YLW	Yellow

Symbol	Meaning
A*P	Printed circuit board
BS*	Pushbutton ON/OFF, operation switch
BZ, H*O	Buzzer
C*	Capacitor



⁽¹⁾ Field settings are defined as follows:



- **M:** Mode number – **First number:** for group of units – **Number between brackets:** for individual unit
- **SW:** Setting number / **C1:** First code number
- **—:** Value number / **C2:** Second code number
- **—:** Default



9 Technical data

Symbol	Meaning
AC*, CN*, E*, HA*, HE*, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R_*, NE	Connection, connector
D*, V*D	Diode
DB*	Diode bridge
DS*	DIP switch
E*H	Heater
FU*, F*U, (for characteristics, refer to PCB inside your unit)	Fuse
FG*	Connector (frame ground)
H*	Harness
H*P, LED*, V*L	Pilot lamp, light emitting diode
HAP	Light emitting diode (service monitor green)
HIGH VOLTAGE	High voltage
IES	Intelligent eye sensor
IPM*	Intelligent power module
K*R, KCR, KFR, KHuR, K*M	Magnetic relay
L	Live
L*	Coil
L*R	Reactor
M*	Stepper motor
M*C	Compressor motor
M*F	Fan motor
M*P	Drain pump motor
M*S	Swing motor
MR*, MRCW*, MRM*, MRN*	Magnetic relay
N	Neutral
n=*, N=*	Number of passes through ferrite core
PAM	Pulse-amplitude modulation
PCB*	Printed circuit board
PM*	Power module
PS	Switching power supply
PTC*	PTC thermistor
Q*	Insulated gate bipolar transistor (IGBT)
Q*C	Circuit breaker
Q*DI, KLM	Earth leak circuit breaker
Q*L	Overload protector
Q*M	Thermo switch
Q*R	Residual current device
R*	Resistor
R*T	Thermistor
RC	Receiver
S*C	Limit switch
S*L	Float switch
S*NG	Refrigerant leak detector
S*NPH	Pressure sensor (high)
S*NPL	Pressure sensor (low)
S*PH, HPS*	Pressure switch (high)
S*PL	Pressure switch (low)
S*T	Thermostat
S*RH	Humidity sensor
S*W, SW*	Operation switch
SA*, F1S	Surge arrester

Symbol	Meaning
SR*, WLU	Signal receiver
SS*	Selector switch
SHEET METAL	Terminal strip fixed plate
T*R	Transformer
TC, TRC	Transmitter
V*, R*V	Varistor
V*R	Diode bridge, Insulated-gate bipolar transistor (IGBT) power module
WRC	Wireless remote controller
X*	Terminal
X*M	Terminal strip (block)
Y*E	Electronic expansion valve coil
Y*R, Y*S	Reversing solenoid valve coil
Z*C	Ferrite core
ZF, Z*F	Noise filter







**DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.**

U Nové Hospody 1155/1, 301 00 Plzeň Skvrňany, Czech Republic

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

Copyright 2017 Daikin

4P472267-1C 2025.06